



2107 West Blue Heron Blvd.
Riviera Beach, FL 33404
Phone: 561-845-2425
Toll Free: 800-327-6880
www.itwconsumer.com

Bath & Tub Repair Kit

White or Almond/Bisque

Technical Data Sheet

Rev 11/08

PRODUCT DESCRIPTION: Repair kit repairs small holes and cracks in bath and tub fixtures. Kit mixes to a white color, but can add the pigment for almond/bisque pigment color matching.

WORKS BEST ON: Use to repair bathtubs, shower stalls, surrounds and sinks. For use on plastic, fiberglass and ceramics.

PRODUCT FEATURES:

- Tensile Strength: 1,500 psi
- Color: White OR Almond/Bisque
- Water Resistant
- Working Time: 4 – 5 Minutes
- Set Time: 20 Minutes
- Full Bond: up to 24 Hours
- Temperature Range: 40°F to 200°F (Temperatures below 40°F (5°C) slows the curing time)
- Chemical Resistance: Moisture, acid, alkali, water, petroleum products
- Storage: Store in a cool, dry environment.

SURFACE PREPARATION: Protect work area from accidental spills. Slightly roughen repair area. Clean surface thoroughly (free of dirt, soap scum, cleaning chemical residue or other contaminants).

REMOVAL METHODS: (test inconspicuous area of item to be sure chemicals do not harm surface)

Before epoxy is allowed to dry, remove excess immediately with damp cloth. Can also use mineral spirits or isopropyl alcohol.

After cure:

Metal/Ceramic/Glass: Soak in hot water, if possible. Heat in excess of 350°F, this will weaken the bond. Solvents that can be used: isopropyl alcohol, acetone, methylene chloride or other solvent.

Fabric: Before epoxy cures, immediately flush fabric with warm water or wipe with a damp cloth. Once epoxy is cured, it is not possible to remove it from the fabric.

HELPFUL HINTS: Heat is generated while the epoxy mixture cures; the more epoxy and hardener that is mixed together.

Equal portions of the hardener and resin must be thoroughly mixed together in order for this product to cure properly. The most common problem with a two-part epoxy product is not mixing it thoroughly; it will not cure and will remain tacky. Once the product is thoroughly mixed, it can be applied to the repair area(s). *Please note, during the mixing process, be sure to push the sides and bottom of the pouch into the mixture so that you are mixing all of the epoxy resin and hardener together.*

Have the repair area ready before mixing the epoxy hardener and resin together, so that you can begin repair as soon as the pouch contents are thoroughly mix.

For larger repairs, multiple kits may be used; however, you will need to work with one kit at time.

Removable tape is good for putting on an area that you don't want any adhesive/epoxy to get on. Before the epoxy cures, remove the tape.

See MSDS for more complete information, safe handling instructions and first aid.

Non-Regulated

Part Number(s): 90216



The technical data contained herein are intended as a reference only